

Anchor Step Column Units 20"

Directions:

Split Anchor Step Units in half along the 16" splitface

Place units exposing only the splitface side, one 8" units, then one 12"

Rotate each additional layer 90 degrees to offset the running bond.

Example:

